





40005



# 1



# 2



2




1



2




3



4



6



5



7



8



9



10




11



12



1



2




13







14



15



16






1




2



3



17







1




2




3



4



18





1



2



3





1



2



3



4



4



5




6




7




1




2



8




1




2



9



19





1x  
370024



2x  
300501



1x  
4160228



1x  
302301



2x  
614101



1x  
4244363



1x  
368026



2x  
395626



2x  
366501



2x  
4121932



1x  
4540203



3x  
4114084



1x  
4118790



3x  
4114309



1x  
4155708



4x  
4161734



4x  
4109995



1x  
4118866



2x  
4211150



3x  
4211201



4x  
4211202



4x  
4211221



2x  
4508616



2x  
4216625



5x  
4225869



6x  
4216695



2x  
4211189



2x  
4211242



7x  
4211149



4x  
4211210



4x  
4216668



1x  
4211225



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

[www.lego.com/service](http://www.lego.com/service) or dial



00800 5346 5555 :



1-800-422-5346 :



FREE! GRATIS! GRATUIT!

LEGO

club  
MAGAZINE

www.LEGOclub.com



00800 5346 5555



1-866-534-6258 • 1-877-518-5346

USA & Canada only

Outside your area

\* Inexpensive. Mobile charges may apply. \* Numéro sans Frais. Des Frais peuvent s'appliquer avec les téléphones cellulaires.  
\* Gebührenfrei, Kosten für Anrufe aus Mobilfunknetzen können anfallen. \* Gratis telefonnummer, kost\* veder ligg.  
\* Det er ett gratis nummer, når du ringer fra Postbetjening. \* Det er gratis, når du ringer fra en Post betjening.



VISIT THE WORLD'S  
BIGGEST LEGO® SHOP!

www.LEGOshop.com

