





CITY



60127



LEGO.com/city











1x




1x


1







2






3




4





1x

5



8




1x



1x

6





1x




1x

7





1






1x



2x

2




1x



1x



3





2x



4






2x


5




2x

6





7






1x



1x

8




1x



1x


9






1x


10





1x


11



2x


1x


12





1



2






13






1





1x


2






1x

3



1x


4








1x

5






6




7





2x



8






1x

9



1x


10





1x



11






1x

12



2x


13





2x

14







1x




1x

15



2x

16





CITY



60090



60091



60092



60093



60095

LEGO.COM/CITY



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346