

7595




2



1



2




3

3



4

4



5




6



5

11




6


12



13




14




9

15



10


16



17



18



11

19



12



1x 7336	4x 4212471	1x 4598175	4x 400970	2x 371028	1x 4560055	4x 4005696
2x 3002308	1x 4563895	1x 4563724	1x 4562718	2x 300228	2x 4569553	4x 4562673
2x 4217725	4x 4077120	1x 4566873	4x 4569749	1x 4570476	2x 4003725	4x 4568991
1x 4013290	1x 543128	4x 74040	2x 4521931	2x 300128	2x 4142989	2x 4142717
1x 421397	2x 4279565	1x 4566872		1x 300028		
1x 3000748	2x 4568993					
1x 4578483	2x 4077782	1x 3034018				

Customer Service

Kundenservice

Servicio al Consumidor

Servizio Al Cliente

www.lego.com/service or dial

00800 5346 5555

1-800-422-5346