



40153




1-99






2x

1



1x


2



3




1x



1x

3




4



2x

4






2x



2x

5




1x



2x

6





2x



1x

7






1x




1x

8



1x

9






2x





1x

10

1



2






3x



4x

11




2x



2x

12







1x



2x

13





1x

1



1x



1x



1x

2






1x



1x

3



1x



1x

4






1x



1x


3



3

1:1

5



3



14





2x



2x



2x

15



1x



2x

16





2x



2x

17



4x

18





4x

19



3x

20





2x



2x




2x




2x

21







1



2





1x

3






4x



4x

4




5






22





23





24







4x
4178429



1x
396001



1x
4203583



4x
4215470



1x
302201



2x
302301



3x
306901



2x
6051511



4x
4547649



3x
4114306



4x
6006805



3x
4569382



8x
6022004



2x
4216695



1x
4211189



4x
4636170



1x
4659004



1x
6034839



4x
614121



1x
6023459



1x
300321



1x
329821



2x
245821



1x
6036408



1x
373821



1x
486523



1x
4112874



1x
300423



1x
301023



1x
300123



1x
614323



1x
4565319



1x
362323



4x
614123



4x
4143005



2x
4529235



2x
4558172



1x
6123714



8x
300524



2x
4504381



2x
6069170



2x
307024



4x
362324



3x
302424



1x
281726



1x
4198367



4x
306540



2x
4649066



1x
6017001



1x
4211815



1x
4211639



1x
6060795



2x
6061678



4x
6021999

Customer Service
Kundenservice
Service Consommateurs
Servicio Al Consumidor
LEGO.com/service or dial

00800 5346 5555 :
1-800-422-5346 :



LEGO and the LEGO logo are trademarks of the/
sont des marques de commerce du/son marcas
registradas de LEGO Group.
©2015 The LEGO Group. 6125306